
Installation




- 1. Pls use the card to measure hole position correctly and drill 2 holes.
- 2. Fix 2 expansion plugs into the holes.
- Fix a screw to the lower expansion plug with a spare space, insert the notch onto the screw.
- 4. Straighten the whole lamp and fasten the upper screw.
- 5. Press the button to adjust to demanded working mode.

Notice

- 1. Pls install this light onto flat surface directionally to get enough solar.
- The lamp will light up when the environmental brightness is less than 30lux.
- 3. Inside battery is replaceable, 18650 Li-ion battery, 1200mAh/3.7V.
- 4. Lamp need to be installed 2-4Mtr from the ground.













Model: VT-767-2

Please read and follow all instructions to operate. Save this manual for future reference. WEEE Number:80133970

Specification

SKU	8276/8277
Power/Lumen	1.5 W / 220LM
LEDs	SMD2835*14PCS
Li-ion Battery	1200 mAh / 3.7V, 18650
Solar Panel	0.7Wp, Poly-crystalline silicon
Working Mode	2 different lighting modes
Detection Angle/Area	90°/ 2-6Mtr
Visible Distance	6-7Mtr
IP Degree	IP 65
Lifespan	35,000hrs
Installation Height	2-4Mtr

Features



Outdoor



Solar Powered




AUTO Light on/off automatically






Working Modes



Pls press the Button to adjust working mode:

Press 1st time for Mode A. Press 2nd time for Mode B. Press 3rd time for off.



Mode A:Automatically turns on to full brightness (220lm) when motion is detected in the range ≤6 mtrs and then turns to weak brightness (front light on & back light on) in 10 seconds of no motion.



Mode B:Automatically turns on to full brightness (220lm) when motion is detected in the range ≤6 mtrs and then turns to weak brightness (front light off & back light on) in 10 seconds of no motion.